

Inspect the spaces people should not enter.



WATER & WASTEWATER

OPERATIONAL PRESSURE

Utilities operate dispersed, ageing and often hard-to-access assets while leaks, blockages, corrosion, gas and equipment degradation compete for limited maintenance attention.

QUANTEON RESPONSE

Quanteon combines network context, fixed instrumentation, inspection devices and field observations to qualify what changed and which intervention deserves priority.

MISSION PORTFOLIO

Illustrative mission patterns · platform and payload subject to site qualification



Pump-station condition route

Thermal · vibration · gas



Sewer and culvert inspection

Visual · sonar · gas



Tank and reservoir survey

Visual · thermal · mapping



Leak and overflow evidence fusion

Flow · level · reports · weather

IDEAL CUSTOMER PROFILE

- Water and wastewater utility leadership
- Operations, networks and treatment
- Maintenance, asset management and safety

START WITH ONE MISSION

Baseline one pump-station, sewer, tank or treatment-asset route tied to a work-order decision.

ASSURED MISSION BASELINE

10 working days · CHF 25k fixed · no hardware purchase

SCOPE A MISSION

